IONA Side Tables

Assembly instructions
















Parts







Hardware



Item A - 1 x Threaded rod (24cm) Carton 2



Item B - 1 x Rod connector nut Carton 2



Item C - 1 x Threaded rod (33cm) Carton 3



Item D - 5 x Felt feet **Carton 3**



Item E - 1 x Locking nut Carton 2




Item F - 1 x Spanner (Tube shaped) Carton 3

Assembly Stages


Stage 1

Lay the top upside down so the central fixing point is facing upwards. Take the threaded rod (Item A) and screw this into the fixing point on the top until it is tight and secure.




Stage 2

Take the **Riser** from Carton 2 and gently slide it over the threaded rod until it reaches the fixing point. Make sure the locking tooth on the riser drops into its matching slot.




Stage 3

Next, you need to extend the threaded rod using the Rod connector nut (Item B) and the other threaded rod (Item C). Screw half of connector nut onto the fixed threaded rod so the other half of the nut can be used with the other threaded rod.




Stage 4

Slide the Base (Carton 3) over the threaded rod. Make sure the locking tooth on the base drops into the matching slot



Stage 5

Take item E and screw it onto the remainder of the threaded rod. Use Item F to tighten the nut.



Stage 6

Finally stick all of **ITEM D** to the bottom of the base to protect your floor. Once this has been done you can flip the table over. **WARNING: DO NOT pivot the table on its top when turning over. Due to the weight of the base this could damage the top.**

