


1

IMPORTANT - When lifting the unit into its upright position DO NOT pivot it on its legs.



2